

















SIERRA 5x2.4 Skrzynia/Storage

Instrukcja montażu/Assembly instructions







A14-sa x1

ST5x14mm



A30-sa x4

ST6x16mm




A31-sa x24

M6x14mm




A32-sa x10

M6x16mm




A33-sa x1

M6




A34-sa x3

M8








A35-sa x4









A14.1-sa x4



A14.2-sa x4







2




3



A2-sa x1










4




A5-sa x1



A30-sa x2




5



A4-sa x1




A30-sa x2




A2/3-sa

A4-sa



A4-sa




A3-sa

A5-sa

A2-sa

A4-sa




A4-sa

A3-sa

A5-sa

A2-sa



A4-sa

A2/3-sa

6



A6-sa x1



A10-sa x1




A11-sa x1




A31-sa x6




A32-sa x2



A34-sa x2






7




A9-sa x1



A31-sa x6



8




A7-sa x1





A8-sa x1



A13-sa x2







A35-sa x4



9







A31-sa x12



10



A32-sa x8




11




A12-sa x1





A33-sa x1



A34-sa x1




A12-sa



12







A14-sa x1



A14.1-sa x4



A14.2-sa x4



Otwór kieszeni z siatki jest skierowany ku górze/
The opening of the net bag is facing up

